

## Bluetooth Remote Programming Guide

### Programming Remote for a TV or Audio Device:

1. Turn on the device you wish to program.
2. Press and hold the OK + MUTE on the remote until the light flashes twice at the top of the remote.
3. Type in the 5 digit code for the brand of your device (see code list on following page).
4. Aim the remote at the device and press the white power button. The device should turn off. If it does not, repeat steps 2 through 4 until the device turns off.

### Pairing Remote to Set-top Box(STB):

1. Turn on the TV and STB.
2. Point remote at STB and hold the OK + Play/Pause until the light starts flashing on the remote. On the screen it should also say the pairing has started.
3. The light should stop flashing on its own within 5-30 seconds and shortly after that, the message on the screen should say that pairing was successful.
4. If the light does not stop flashing after 30 seconds and/or the screen says pairing unsuccessful, press and hold the OK + EXIT until the light stops flashing.
5. Repeat steps 2-4 until successful.

### Programming Remote to STB:

1. Determine what brand STB you have and find it in the table below.
2. Press and hold the OK + DIGIT associated with your STB until the light flashes twice.  
Innovative Systems OK + DIGIT 1  
Amino OK + DIGIT 2 or 4
3. Change the channel to verify functionality.



## Television Brands

888 13636  
Accurian 11803  
Acer 11339, 13630, 14143  
ad notam 14382  
Admiral 13879  
Advent 11570  
Affinity 13111, 13577, 13116  
Afron 10891  
Aiwa 11142  
Akai 11675, 12051, 11688, 11032, 11692, 11207, 11385, 11670, 12232. 13477  
Alba 12372  
AOC 11589, 11365, 12014, 12087, 12621, 11590, 11348  
Aomni 11623  
Apex Digital 12397, 11217, 14350, 10890  
Ario 12397  
Astar 11531, 11738  
Asus 13340, 11867  
Atak 12397  
Atvio 11531, 13478, 10891, 13636, 13879  
Atyme 12746  
Audiovox 11868, 11276, 11564, 10846, 12413, 10802, 11766, 11769, 13065, 11803  
Auria 12014, 13519, 12087, 12855  
Aventura 11394  
Avera 12397, 12049  
Avol 13382, 12735, 12397  
Awa 12480  
Axen 12397  
Axess 13593, 14888  
Axion 12049  
BBK 12098  
BenQ 11562, 11315, 11032, 11738, 11746  
Blu:sens 12735  
Bolvn 12397  
Boss Audio System 11314  
Bravis 13477  
Broksonic 11670, 11892  
Bush 12360  
Byd:syn 11311  
Calypso 13519  
Casio 11205  
Champion 11142  
Changhong 13477, 11589  
Chrtstie 14951  
Cineon 13951  
Citizen 10802, 11670, 11671, 11672  
Claris 13807

Coby 13478, 12315, 12306, 12344, 12314, 12345, 11634, 12338, 12326, 12340, 13629, 11538, 11738, 13493, 13646  
Commercial Solutions 11447  
Contex 14053  
Cornea 13877  
Craig 13423  
Curtis 12855, 13577, 12397, 13895, 12352, 11523, 14053, 13636, 11326, 11314, 13382, 13595, 13717, 13899, 14093  
Curtis Mathes 12051, 11661, 12496  
Cytron 11326  
D.Boss 11314  
Daewoo 11661, 10661, 12434, 11032  
Daytek 13651  
Dell 11264, 12372, 12731  
Delta Electronics 11369  
DiBoss 11314  
Digital Lifestyles 11765  
Digitrex 14207  
Disney 11892, 11394  
DNS 13879  
Dukane 11398, 11457  
Dumont 10017  
Durabrand 11398, 11570, 11034  
Dynex 12049, 11892  
Eagle Kingdom Technology 14083  
EKT 14083  
Electric Mirror 13166  
Electrograph 11623, 11755  
Electrohome 11672, 11570, 11670  
Electron 12397, 12855  
Elektra 10017, 11661  
Element 13559, 14398, 11523, 13519, 12964, 11864, 12746, 14660  
Elite 11457  
Emerson 11864, 11394, 11963, 12372, 11661, 13519, 13559  
Emprex 11422, 11765  
Encross 11314  
Envision 11589, 11365, 12087, 12014, 10813, 12621, 12372  
Epson 11122  
Epworth 11142  
EQD 12014, 12087  
EQD Auria 12014, 12087  
ESA 11394, 12051, 11963  
eTec 12397  
Exorvision 13559  
Favi 13382  
Fisher 11142  
Fluid 12964, 13559  
Fujitsu 10853, 10809, 10683  
Funai 11394, 11864, 11963

Furrion 13332, 14093  
Gateway 11755, 11756  
GE 11447  
General Electric 11447  
GFM 11864, 11394, 11963, 11866  
GHIA 15144, 15196  
Gibraltar 10017  
Go Video 11738, 11641, 11826  
GPX 13980, 13977, 12693, 13402, 12784  
Grundig 12372, 10683  
Haler 12309, 13382, 14112, 11712, 14398, 11589, 12205, 13601, 12352, 12494, 11032, 11034, 11570, 13204, 13928  
Hannspree 11348, 11745  
Harper 14053  
Helios 10865  
Hewlett Packard 11642, 12731, 11867  
Hidear 13817  
Hisense 13519, 14740, 12098, 13808, 11660, 12049, 11314, 13382, 14398  
Hitachi 11643, 14398, 11345, 11576, 11589, 13382, 11457, 12372, 13332, 14557, 11480, 11670  
Hiteker 13382  
HKPro 13879, 12434, 14083  
HP 11642, 12731, 11867  
Hyundai 13418, 10849, 11219, 12372, 14053, 13519  
I-Inc 11746  
iLo 11394, 11684, 11990, 11603, 11892, 11286  
Initial 11990, 11603  
Insignia 12049, 11564, 11328, 11841, 11385, 11892, 11204, 12731, 11517, 11394, 15213, 11660, 11963, 11603, 12751  
Inteq 10017  
iRIS 12189  
iSymphony 13382, 13094  
Izumi 14053  
JCM 12189, 12746  
Jensen 11326, 13204, 12541  
JVC 11774, 14398, 12118, 12321 13382, 11524, 14053, 14105, 11570, 11670 11480. 13592, 13793, 10683, 11892  
jWin 13382  
Kalley 13879  
KC 14182, 15222  
KDS 11523  
Kenmore 13559  
Kingston 13284  
Kogan 14053  
Kolin 12731  
Konka 11385, 11641  
Kost 11314  
Kreisen 11314  
Lasonic 13198  
LeEco 14007, 14137

Legend 12397, 12309, 12352  
Lenco 13332  
Lexus 11531, 13478  
LG 12731, 10017, 14398, 11314, 11768, 12867, 12309  
Liberton 12434  
Lloyd's 13382  
LodgingStar 13147  
LXI 10017, 11524  
MAG 11523  
Magnavox 12372, 11867, 11963, 11990, 12665, 11198, 11365, 11755, 11394, 10802, 14398  
Marantz 11398, 12372  
Matsushita 11480  
Maxent 11755, 11757  
MB Quart 11868  
Memorex 11570, 14686, 11523, 11670, 11892, 11394, 12049, 10150, 11671, 12739  
MGA 10150  
Micro 11314  
MicroTEK 13951  
Midland 10017  
Mintek 11603, 11990  
Misakae 11394  
Misakai 11394  
Mitsubishi 10150, 11250, 11797  
Mitsui 10891, 12063, 11385, 11531, 13478  
NAD 11524  
Naoki 13477  
Naxa 14093, 12104, 12735, 12397, 13382, 13423, 14636, 14888  
NEC 13257, 11797, 11398, 11704, 13000, 11712, 11314  
NetTV 11755, 11286  
New Acoustic Dimension 11524  
Nexus 11564, 13519  
Nexus Electronics 13519  
Nikko 10017, 11524  
Niko 11581, 11745  
Norcent 11365, 11589, 10824, 11581, 11590, 11745  
Norwood Micro 11286, 10802  
NuVision 12158, 11657, 12397  
oCOSMO 13899  
Olevia 11610, 12731, 11144  
Onn 12397, 12434, 15118  
Optimus 11480, 11457  
Optique 12189  
Orion 11892, 11774, 13559  
Palsonic 12461, 11276  
Panasonic 11480, 10150, 11394, 11524  
Pantel 13259, 13261  
PDI 11314  
Peerless-AV 14254  
Penney 11524

Philco 11394, 11963  
Philips 11867, 12372, 12665, 12622, 11394, 13678, 14398, 10017, 11990, 11755, 11963, 11365, 11589, 11198, 11314, 11756  
Philips Magnavox 12372, 11867, 11394  
Pioneer 11457, 11398, 13254, 12434  
Planar 14951, 11457, 11589, 11738, 12014  
Polaroid 11523, 11769, 11276, 15037, 11385, 11538, 11767, 13793, 13382, 11032, 11762, 10865, 11314, 11326, 11766, 12063, 11286, 11316, 12120, 12434  
Portland 11661  
Prima 12309, 12049  
Proscan 13577, 13382, 13519, 13717, 12746, 13332, 14053, 14494, 13636, 13559, 13895, 11523, 13899, 14483, 14375, 15288, 12147, 14207, 14499, 14686, 14093, 11447  
Proton 11765  
Proview 11523  
Pulsar 10017  
Pyle 12196, 12641, 13905  
Pyle Home 12196  
QFX 13593  
QuantumFX 13593, 12337  
Quasar 14207, 13382, 13899 15221 11480  
Qumi 11369  
RCA 12746, 12434, 13577, 13382, 13332, 13111, 13477, 12932, 11447, 14053, 14494, 13895, 14740, 14394, 13559, 14627, 13519, 13636, 12655, 14079, 13147, 13899, 11385, 11457, 11523, 14483, 11661, 11868, 13938, 14093, 14398, 14638, 11670  
RevolutionHD 11623  
Runco 11457, 11398, 10017  
Salora 14053  
Sampo 11755  
Samsung 12051, 13993, 12596, 10766, 10814, 11480, 11692, 11670, 14053, 11409, 14442, 11394, 13559  
Sansui 11892, 11670, 14053, 11409, 14442, 11394, 13559  
Sanyo 11142, 12372, 12049, 14740, 12461, 11276, 11480, 11564  
Sceptre 13899, 12337, 11712, 11217, 11360, 11599, 10876, 12506  
Scott 11711  
Sears 11394, 11524  
Seiki 13559, 12964, 12196, 13382, 15121  
Seiko Epson 11122  
Seleco 11348  
Sens 12309, 11868  
Seura 14303, 14928  
Sharp 12360, 13519, 14740, 11589, 12104, 11670, 14398  
Sherwood 11399, 13061  
Sigmac 13477, 13423  
Silo 14758, 13899, 14494, 13477, 14182  
Silo Digilal 14758, 13899, 14494, 13477, 14182  
SkyVue 14135, 12360  
Skyworth 12372, 15219, 11314, 11799  
Smart Tech 14053  
Sole 11314, 11623, 14549

Sony 10810, 11685  
Soyo 11826, 11765, 11746, 11641, 11830  
Spectroniq 11523  
Speler 14105, 13717, 12434  
Squareview 11394  
SunBriteTV 12337, 11420, 11610, 13899  
Superscan 10864, 11394  
Supersonic 13593, 12397, 13877, 14888, 12104, 12309, 13595, 12764, 13147, 13204  
Supra 13332, 11641, 13477  
SVA 10865, 11963  
Sylvania 11394, 11864, 11963, 11314, 13332, 13577, 14053  
Symphonic 11394, 11963  
Syntax 11610, 12731, 11144  
Taki 13477  
Talung 11286, 12496, 11756  
TCL 14398, 12434, 13879  
Technicolor 13577  
Technics 11480, 10017  
Technika 12372  
Techview 10847  
Teknika 10150  
Telefunken 12051  
TNCi 10017  
Tosaki 13477, 11385  
Toshiba 11524, 15213, 13477, 11670, 11704, 11343, 11480, 11369, 12731, 12802  
Toshinaer 11746  
TruTech 11394, 11723  
Tyler 14888  
Upstar 14182, 14405, 13899  
US Logic 11286  
V7 Videoseven 12087  
Venturer 11868  
VEON 14053  
Vidao 12397  
Vidoseven 12087  
Vidikron 11398, 11457  
Viewsonic 12014, 11627, 11738, 12087, 11755, 10864, 11330, 12049, 12111, 10885, 12731, 11457, 11564, 11578, 11589, 11742, 11365, 11511, 11745  
Viore 13362, 12352, 12104, 12496, 13094, 11684, 11207, 13574, 14105, 12397  
VisionQuest 11523, 11738, 12397, 13380  
Vividtouch 14951  
Vivitech 11369  
VIZIO 11758, 12707, 11756, 10864, 10885  
Vuon 13418  
W Box Technologies 14686  
Wards 10017, 11524  
Waycon 11524  
Westinghouse 11712, 13559, 13362, 10885, 13094, 12196, 10890, 11282, 12397, 13909, 147911, 11217  
White Westinghouse 11661

WinBook 11369  
Wyse 11365  
Xoceco 12309, 12049  
Yamaha 11643  
Zenith 10017, 11643, 12731, 11661, 11365, 11892

## **Audio Brands**

Accurian 21609  
Acoustic Audio 24683, 24907  
Aiwa 21641, 20189  
Alco 21390  
Altec Lansing 22595, 21485, 24609, 22720, 22138  
AMC 21077  
Anam 21609  
Anthem 21609, 23835, 22220  
Anthem Statement 21609, 23835, 22220  
Apex Digital 24334  
Arcam 21289, 22138, 20189, 22241  
Arvani 22454  
Audio Blast 21289  
Audio Control 21289  
Audio Net 22138  
Audio Solutions 23622  
AudioControl 21289  
Audioengine 24311  
AudioSource 23721  
Audiotronic 21289  
Audiovox 21390  
Aura 22454  
Auvio 25106  
Axess 24095  
Axiim 24951  
B & W 23965, 22441, 23943  
BOHM 24280  
Bose 21629, 21933, 24307, 21841, 23708, 24024, 25230, 23708, 24024, 25230, 23706, 23832  
Boston Acoustics 23698  
Bowers & Wilkins 23965, 22441, 23943  
Cambridge Audio 22138  
Canston 25138  
Carver 20189, 22138, 21289  
Classe 21918, 21915  
Clatronic 21918  
Coby 21389, 23654, 23218  
Craig 24465, 24466  
Current Audio 25190, 25191  
Curtis 21389, 23942  
Curtis Mathes 20823



Cyrus 22138  
Definitive Technology 24415, 24026, 23645  
Denon 22857, 23347, 23643, 23642, 22279, 22706, 22502, 24025, 24054, 21289  
Durabrand 21561  
Dynavox 23231  
Dynex 22584, 23951  
Emotiva 23763, 24059, 24101, 24641  
Enclave Audio 24800  
Energy 23915  
Energy Sistem 23915  
Episode 25115, 25107  
Epworth 21641, 20189  
Gateway 21077, 21517  
GE 22611  
General Electric 22611  
Go Video 21868  
GPX 25103, 21389  
Haier 23516  
Halcro 21289, 22138  
Harman/Kardon 22241, 23391, 22660  
iLive 23175  
Inkel 23120, 23770, 21077, 24090  
Insignia 23951, 21077, 22175, 21030, 22472, 24424, 22584, 21751, 23770, 22583  
Integra 21805, 21320, 23992  
iWave 24971  
Jamo 23915  
JBL 23756, 22287, 22241, 23391, 23535  
Jensen 21389  
JVC 21676, 23049, 21868  
Kenwood 21570, 22197  
KLH 21390  
Klipsch 23915, 24198, 24200, 25152  
Koss 21266  
Krell 22138  
Lenoxx 21561  
Leon 24233  
LG 22197, 23217, 22676, 22284  
Linn 22138, 20189  
Liquid Video 21266  
Logitech 21408  
Magnavox 20189, 21831, 23282, 22138, 21289  
Marantz 21289, 22138, 20189, 21831, 23347, 24118  
Martin Logan 23526, 24271  
McIntosh 21289  
Micromega 21289  
Monoprice 24505  
Musicmagic 20189  
Myryad 21831, 21289  
NAD 20320, 21609

Nakamichi 21570  
New Acoustic Dimension 20320, 21609  
NexxTech 21751  
Norcent 21389, 21751  
Nova 21389  
Nu Force 23968  
Onkyo 21805, 21320, 24041, 23992, 24533, 23984, 23326  
Onn 25042, 25041  
Optimus 21935, 20823  
Orbitsound 24098  
Oritron 21266  
Outlaw 21709  
Panasonic 22967, 23055, 21633, 23323, 23767, 21676  
Paradigm 24536, 23526, 24555, 24846  
PeachtreeAudio 24522  
Peerless-AV 25153  
Philco 21390, 21831  
Philips 21831, 20189, 22459, 23962, 22289, 23379, 23282, 21266, 22675, 22138, 21289, 24382  
Philips Magnavox 20189  
Pinnacle Speakers 23774, 23728  
Pioneer 21935, 21384, 20823, 23384, 23956  
Polk Audio 23429, 21289, 22242, 22138, 20189  
Proficient 23661  
Proscan 21254  
Pyle 23705, 24333  
RCA 21254, 22611, 21935, 22655, 20823, 23969, 21390, 21609, 22544  
RichSoundResearch 25138  
Rotel 23896, 21676  
RSR 25138  
Samsung 21868, 22660, 22137, 22241  
Sansui 20189  
Sanyo 24176, 23282  
Scandyna 22348  
Scott 21609  
Sharp 23736, 23097, 23929  
Sherbourn 23763  
Sherwood 21077, 23120, 21517, 23136, 24090, 23770, 24424  
Sherwood Newcastle 21077  
Simaudio 22138  
SnapAV 25115, 25107  
Sonos 23919  
Sony 22172, 21058, 21622, 23700, 22582, 23487  
SpeakerCraft 23661  
Stereophonics 21935  
Sunfire 21570  
TAD 20823  
Teac 21609, 21390, 24333  
Technics 21633, 22967  
The Gryphon 22138

Thorens 21289

Toshiba 23627, 21320, 21935

TruAudio 24940

Venturer 21390

VIZIO 22454, 25095

Yamaha 22467, 22061, 20176, 22458, 21331, 23667, 22021, 23267, 21422

Zenith 22197, 22284

ZVOX 22332, 23913, 22334